


OILER KIT ASSEMBLY

FOR ALASKAN MILL MK III

MODEL G801A

P/N 699 CLAMP



P/N 677A OILER TANK

P/N 651 TANK INSERT

P/N 652 VALVE

P/N 828A SHOCK PAD

P/N 802F MOUNTING BASE
(INSERT MOUNTING BASE INTO
ADJUSTMENT POST BEFORE
ASSEMBLING OILER KIT)

P/N 689 HOSE

P/N 792 ADJUSTMENT
POST- NOSE END
(REFERENCE ONLY)

P/N 687 JAM NUT

CHAIN SAW BAR
(REFERENCE ONLY)

.....
• SEE REVERSE SIDE OF SHEET
• FOR BAR DRILLING INSTRUCTIONS
•

P/N 967 BAR OIL INJECTOR

BAR DRILLING

BAR STEEL IS VERY HARD. TO DRILL, **DO NOT EXCEED 80 RPM** OR THE BAR WILL HARDEN AND MAKE DRILLING **IMPOSSIBLE**. IF LOW SPEED IS NOT AVAILABLE, USE THE DRILL PRESS FOR PRES-SURE ONLY, AND TURN THE CHUCK BY HAND USING A ROD IN-SERTEED INTO THE DRILL CHUCK.

DIRECTIONS FOR DRILLING OIL INJECTOR HOLES

MODEL G801A

